



3 June 2008

## AgGPS EZ-Boom 2010 Automated Application Control System: Supported Platforms

This Support Bulletin lists platforms that are supported by the AgGPS® EZ-Boom® 2010 automated application control system from Trimble.

Make	Series	Model	Support	Install kit P/N	Install notes	Additional comments
AGCO	Spra-Coupe	20 series: Standard polarity	Rate and boom	64671-00	64671-00-ENG	
AGCO	Spra-Coupe	20 series: Reverse polarity	Rate and boom	64671-00 & 65172-00	64671-00-ENG	Reverse polarity requires both the 64671-00 and the 65172-00 kits. If you are unsure if a system is normal or reverse polarity, contact Trimble Technical Support.
AGCO	Spra-Coupe	30 series: Standard polarity	Rate and boom	64671-00	64671-00-ENG	
AGCO	Spra-Coupe	30 series: Reverse polarity	Rate and boom	64671-00 & 65172-00	64671-00-ENG	Reverse polarity requires both the 64671-00 and the 65172-00 kits. If you are unsure if a system is normal or reverse polarity, contact Trimble Technical Support.
AGCO	Spra-Coupe	40 series: Standard polarity	Rate and boom	64671-00	64671-00-ENG	
AGCO	Spra-Coupe	40 series: Reverse polarity	Rate and boom	64671-00 & 65172-00	64671-00-ENG	Reverse polarity requires both the 64671-00 and the 65172-00 kits. If you are unsure if a system is normal or reverse polarity, contact Trimble Technical Support.

**This document is for informational purposes only and is not a legally binding agreement or offer. Trimble makes no warranties and assumes no obligations or liabilities hereunder.**

Trimble Navigation Limited, Agriculture Division, 10355 Westmoor Drive, Suite #100, Westminster, CO 80021, USA

© 2007-2008, Trimble Navigation Limited. All rights reserved. Trimble, the Globe & Triangle logo, AgGPS, and EZ-Boom are trademarks of Trimble Navigation Limited, registered in the United States and in other countries. All other trademarks are the property of their respective owners.



Make	Series	Model	Support	Install kit P/N	Install notes	Additional comments
AGCO	Spra-Coupe	50 series: Standard polarity	Rate and boom	64671-00	64671-00-ENG	
AGCO	Spra-Coupe	50 series: Reverse polarity	Rate and boom	64671-00 & 65172-00	64671-00-ENG	Reverse polarity requires both the 64671-00 and the 65172-00 kits. If you are unsure if a system is normal or reverse polarity, contact Trimble Technical Support.
AGCO	Spra-Coupe	55 series: Standard polarity	Rate and boom	64671-00	64671-00-ENG	
AGCO	Spra-Coupe	55 series: Reverse polarity	Rate and boom	64671-00 & 65172-00	64671-00-ENG	Reverse polarity requires both the 64671-00 and the 65172-00 kits. If you are unsure if a system is normal or reverse polarity, contact Trimble Technical Support.
Case IH	SRX100	SP655	Rate and boom	64724-00	64396-00-ENG	
Case IH	SRX160	SP655	Rate and boom	64724-00	64396-00-ENG	
Case IH	SPX	3150	Rate and boom	Standard EZ-Boom harnessing		Plug and play with approved controller, but you must create a jumper cable to bypass the diode; contact Trimble Technical Support. AIM and non-AIM models are supported.
Case IH	SPX	3185	Rate and boom	Standard EZ-Boom harnessing		Plug and play with approved controller, but you must create a jumper cable to bypass the diode; contact Trimble Technical Support. AIM and non-AIM models are supported.
Case IH	SPX	3200	Rate and boom	Standard EZ-Boom harnessing		Plug and play with approved controller, but you must create a jumper cable to bypass the diode; contact Trimble Technical Support. AIM and non-AIM models are supported.

Make	Series	Model	Support	Install kit P/N	Install notes	Additional comments
Case IH	SPX	3310	Rate and boom	Standard EZ-Boom harnessing		Plug and play with approved controller. Viper and 4000 series controllers are not supported. AIM and non-AIM models are supported.
Case IH	SPX	3320	Rate and boom	Standard EZ-Boom harnessing		Plug and play with approved controller. Viper and 4000 series controllers are not supported. AIM and non-AIM models are supported.
Case IH	SPX	4260	Rate and boom	Standard EZ-Boom harnessing		Plug and play with approved controller. Viper and 4000 series controllers are not supported. AIM and non-AIM models are supported.
Case IH	SPX	4410	Rate and boom	Standard EZ-Boom harnessing		Plug and play with approved controller. Viper and 4000 series controllers are not supported. AIM and non-AIM models are supported.
Case IH	SPX	4420	Rate and boom	Standard EZ-Boom harnessing		Plug and play with approved controller. Viper and 4000 series controllers are not supported. AIM and non-AIM models are supported.
Flexi-Coil	68	SP655	Rate and boom	64724-00	64396-00-ENG	
Flexi-Coil	68XL	SP655	Rate and boom	64724-00	64396-00-ENG	
HARDI	Pull Type	HC2500	Boom only	63390-00	63390-00-ENG	The HARDI platform kit only connects to the 39-pin Spray II style connectors. This kit does not support the older 20-pin style connector. If you are unsure of the connector type, contact Trimble Support.

Make	Series	Model	Support	Install kit P/N	Install notes	Additional comments
HARDI	Pull Type	HC5500	Boom only	63390-00	63390-00-ENG	The HARDI platform kit only connects to the 39-pin Spray II style connectors. This kit does not support the older 20-pin style connector. If you are unsure of the connector type, contact Trimble Support. HC5500 <b>ST</b> models or any system with JobComs are not supported.
John Deere	Self propelled	4700	Boom only	62681-00	61593-00-ENG	
John Deere	Self propelled	4710	Boom only	62681-00	61593-00-ENG	
John Deere	Self propelled	4720	Boom only	62681-00	61593-00-ENG	
John Deere	Self propelled	4730	Boom only	62681-00	61593-00-ENG	30 series sprayers have 2 flow meters. If you use the flow meter monitoring cable, tie into the utilized flow meter to obtain accurate readout information.
John Deere	Self propelled	4830	Boom only	62681-00	61593-00-ENG	30 series sprayers have 2 flow meters. If you use the flow meter monitoring cable, tie into the utilized flow meter to obtain accurate readout information.
John Deere	Self propelled	4920	Boom only	62681-00	61593-00-ENG	
John Deere	Self propelled	4930	Boom only	62681-00	61593-00-ENG	30 series sprayers have 2 flow meters. If you use the flow meter monitoring cable, tie into the utilized flow meter to obtain accurate readout information.
New Holland	SF 210	SP655	Rate and boom	64724-00	64396-00-ENG	
New Holland	SF 216	SP655	Rate and boom	64724-00	64396-00-ENG	
Nitro	N1		Rate and boom	Standard EZ-Boom harnessing		Plug and play. No end row nozzle support.

Make	Series	Model	Support	Install kit P/N	Install notes	Additional comments
Nitro	N2		Rate and boom	Standard EZ-Boom harnessing		Plug and play. No end row nozzle support.
Pull Behind	Raven fitted	Raven fitted	Rate and boom	Standard EZ-Boom harnessing		EZ-Boom system will fit pull-behind sprayers outfitted with standard Raven components. If in doubt, contact Trimble Technical Support.

## Supported components

Make	Series	Model	Support	Install kit P/N	Install notes	Additional comments
DICKEY-john	Liquid control components	Valve, flow meter, and pressure sensor	Rate and boom	EZ-Boom full harness		Only supported with full harness.
Micro-Trak	NH <sub>3</sub> control components	NH <sub>3</sub> 500 system	Rate and boom	Contact Micro-Trak	Contact Micro-Trak	Micro-Trak NH <sub>3</sub> 500 allows for 1000–6000 lbs NH <sub>3</sub> per hour. You can purchase the NH <sub>3</sub> 500 kit for the EZ-Boom system (P/N 17606) from Micro-Trak.
Micro-Trak	NH <sub>3</sub> control components	Liquifier system	Rate and boom	Contact Micro-Trak	Contact Micro-Trak	Micro-Trak Liquifier allows for 1500–9000 lbs NH <sub>3</sub> per hour. You can purchase the Liquifier kit for the EZ-Boom system (P/N 17607) from Micro-Trak.
Mid-Tech	Liquid control components	Valve and flow meter	Rate and boom	EZ-Boom full harness		Only supported with full harness.
Raven	Liquid control components	Standard valve, flow meter, and pressure sensor	Rate and boom	Contact Raven	Contact Raven	Contact Trimble Support: Plug and play into existing harnessing depends on controller and platform. Full harness option also supports Raven valves.
Raven	Liquid control components	Fast valve, flow meter, and pressure sensor	Rate and boom	Contact Raven	Contact Raven	Contact Trimble Support: Plug and play into existing harnessing depends on controller and platform. Full harness option also supports Raven valves.
Raven	NH <sub>3</sub> control components	Fast valve and flow meter	Rate and boom	Contact Raven	Contact Raven	Contact Trimble Support: Plug and play into existing harnessing depends on controller and platform. Full harness option also supports Raven valves.
Tee Jet	Liquid control components	Valve and flow meter	Rate and boom	EZ-Boom full harness		Only supported with full harness.

## Supported flow controllers

Make	Series	Support	Install kit P/N	Install notes	Additional comments
Flexi-Coil	SP655	Rate and boom	64724-00	64396-00-ENG	Contact Trimble Technical Support: Controller support depends on platform.
HARDI	HC2500	Boom only	63390-00	63390-00-ENG	The HARDI platform kit only connects to the 39-pin Spray II style connectors. This kit does not support the older 20-pin style connector. If you are unsure of the connector type, contact Trimble Support.
HARDI	HC5500	Boom only	63390-00	63390-00-ENG	The HARDI platform kit only connects to the 39-pin Spray II style connectors. This kit does not support the older 20-pin style connector. If you are unsure of the connector type, contact Trimble Support. HC5500 <b>ST</b> models or any system with JobComs are not supported.
Raven	440	Rate and boom	Standard EZ-Boom harnessing		Contact Trimble Technical Support: Controller support depends on platform.
Raven	450	Rate and boom	Standard EZ-Boom harnessing		Contact Trimble Technical Support: Controller support depends on platform.
Raven	460	Rate and boom	Standard EZ-Boom harnessing		Contact Trimble Technical Support: Controller support depends on platform.
Raven	660	Rate and boom	Standard EZ-Boom harnessing		Contact Trimble Technical Support: Controller support depends on platform.
Raven	660M	Rate and boom	Standard EZ-Boom harnessing		Contact Trimble Technical Support: Controller support depends on platform.
Raven	661	Rate and boom	Standard EZ-Boom harnessing		Contact Trimble Technical Support: Controller support depends on platform.
Raven	4400	Rate and boom	Standard EZ-Boom harnessing		Contact Trimble Technical Support: Controller support depends on platform.
Raven	4600	Rate and boom	Standard EZ-Boom harnessing		Contact Trimble Technical Support: Controller support depends on platform.